




1. Run FW upgrade tool




2. Warning Message



3. FW updater tool will show current version and update FW version



4. Warning Message



5. After Update FW finished, Please un-plug dongle than plug in again.

