

ASM1062 F/W update to 09160000.ROM SOP

Note: Program tool have to run it on real DOS environment, not Windows DOS mode

1. Please unzip RE1062.A23.zip and copy RE1062.A23 folder to C:\
2. Boot into DOS
3. Please into [C:\RE1062.A23](#)
4. Type "ahci.bat" to start update firmware
5. When screen shown "PASS : 1 FAIL : 0" that's mean update finish and successful.
6. Restart PC

Check new Firmware version

Firmware version: 220916_00_00_00